

# **Russound Controllers**

## **RNET™ Protocol & Specifications RS-232 Communication**

**Document version 1.00.01**

## Quick Reference Guide

<u>Feature</u>	<u>CAS44</u>	<u>CAA66</u>	<u>CAM6.6</u>	<u>CAV6.6</u>	<u>Pg.</u>
Keypad Events	•	•	•	•	13
Source Control Events		•	•	•	14
Set Zone On/Off	•	•	•	•	19
Set All Zones On			•	•	19
Set All Zones Off	•	•	•	•	19
Zone Source	•	•	•	•	20
Zone Volume	•	•	•	•	21
Bass	•	•	•	•	22
Treble	•	•	•	•	23
Loudness	•	•	•	•	24
Balance	•	•	•	•	25
Turn On Volume	•	•	•	•	26
Background Color			•	•	27
Do Not Disturb			•	•	28
Party Mode			•	•	29
All Zone Info	○	○	•	•	30
Displaying a String	•	•	•	•	31
Display Messages	•	•	•	•	33

○ = Partially Supported Feature

• = Fully Supported Feature

<b>1</b>	<b>INTRODUCTION</b> .....	<b>5</b>
<b>2</b>	<b>OVERVIEW</b> .....	<b>5</b>
<b>3</b>	<b>COM PORT</b> .....	<b>5</b>
3.1	COM SETTINGS.....	5
3.2	CONNECTOR TYPE / PIN-OUT.....	5
<b>4</b>	<b>RNET™ MESSAGE PACKET FORMAT</b> .....	<b>7</b>
4.1	MESSAGE HEADER.....	7
4.1.1	<i>Start of Message Character</i> .....	7
4.1.2	<i>Target Device ID</i> .....	7
4.1.2.1	Target Controller ID.....	7
4.1.2.2	Target Zone (Port) ID.....	8
4.1.2.3	Target Keypad ID.....	8
4.1.3	<i>Source Device ID</i> .....	9
4.1.3.1	Source Controller ID.....	9
4.1.3.2	Source Zone (Port) ID.....	9
4.1.3.3	Source Keypad ID.....	9
4.1.4	<i>Message Type</i> .....	9
4.2	MESSAGE BODY.....	10
4.2.1	<i>The Invert Character</i> .....	10
4.2.2	<i>Event Messages</i> .....	11
4.2.3	<i>Data Messages</i> .....	11
4.3	MESSAGE TRAILER.....	11
4.3.1	<i>Checksum</i> .....	11
4.3.2	<i>End of Message Character</i> .....	12
<b>5</b>	<b>BUTTONS AND KEYCODES</b> .....	<b>13</b>
5.1	KEYPAD EVENTS.....	13
5.2	SOURCE CONTROL EVENTS.....	14
<b>6</b>	<b>USING REQUEST MESSAGES</b> .....	<b>18</b>
<b>7</b>	<b>ZONES</b> .....	<b>19</b>
7.1	ON/OFF.....	19
7.1.1	<i>Set State</i> .....	19
7.1.2	<i>Get State</i> .....	19
7.1.3	<i>Set All Zones On/Off State</i> .....	19
7.2	SOURCE SELECT.....	20
7.2.1	<i>Set Source</i> .....	20
7.2.2	<i>Get Source</i> .....	20
7.3	VOLUME SELECT.....	21
7.3.1	<i>Set Volume</i> .....	21
7.3.2	<i>Get Volume</i> .....	21
7.4	BASS.....	22
7.4.1	<i>Bass Up/Bass Down</i> .....	22
7.4.2	<i>Set Bass</i> .....	22
7.4.3	<i>Get Bass</i> .....	22
7.5	TREBLE.....	23
7.5.1	<i>Treble Up/Treble Down</i> .....	23
7.5.2	<i>Set Treble</i> .....	23
7.5.3	<i>Get Treble</i> .....	23
7.6	LOUDNESS.....	24
7.6.1	<i>Loudness Toggle On/Off</i> .....	24
7.6.2	<i>Set Loudness</i> .....	24
7.6.3	<i>Get Loudness</i> .....	24
7.7	BALANCE.....	25
7.7.1	<i>Balance Left or Balance Right</i> .....	25
7.7.2	<i>Set Balance</i> .....	25

7.7.3	<i>Get Balance</i> .....	25
7.8	TURN ON VOLUME .....	26
7.8.1	<i>Increase or Decrease Turn On Volume</i> .....	26
7.8.2	<i>Set Turn On Volume</i> .....	26
7.8.3	<i>Get Turn On Volume</i> .....	26
7.9	BACKGROUND COLOR.....	27
7.9.1	<i>Background Color Off/Amber/Green toggle</i> .....	27
7.9.2	<i>Set Background Color</i> .....	27
7.9.3	<i>Get Background Color</i> .....	27
7.10	DO NOT DISTURB .....	28
7.10.1	<i>Do Not Disturb On/Off Toggle</i> .....	28
7.10.2	<i>Set Do Not Disturb</i> .....	28
7.10.3	<i>Get Do Not Disturb</i> .....	28
7.11	PARTY MODE .....	29
7.11.1	<i>Party Mode On, Party Mode Master, and Party Mode Off</i> .....	29
7.11.2	<i>Set Party Mode</i> .....	29
7.11.3	<i>Get Party Mode</i> .....	29
7.12	GET ALL ZONE INFO .....	30
7.12.1	<i>Get State</i> .....	30
<b>8</b>	<b>DISPLAYING A STRING .....</b>	<b>31</b>
8.1	ON ALL KEYPADS .....	31
8.2	ON A SPECIFIC KEYPAD .....	31
<b>9</b>	<b>DISPLAY MESSAGES .....</b>	<b>33</b>
9.1	READING DIRECT DISPLAY FEEDBACK .....	33
9.2	READING SOURCE BROADCAST DISPLAY FEEDBACK .....	34
9.3	READING MULTI-FIELD BROADCAST DISPLAY FEEDBACK MESSAGES .....	35
<b>10</b>	<b>USING THE ACKNOWLEDGE MESSAGE (HANDSHAKING) .....</b>	<b>35</b>
<b>11</b>	<b>ASCII CHARACTER SET TO HEX CONVERSION CHART .....</b>	<b>37</b>
<b>12</b>	<b>RUSSOUND CONTROLLERS RS-232 HEX CODE LISTING .....</b>	<b>38</b>

# 1 Introduction

This document describes how to control and interpret data from Russound controllers. Remote access is provided through the RS-232 serial port found on the front (CAV only) or rear of the controller using the following **RNET™** communications protocol. It is assumed that the reader is familiar with the features and operation of the controller being used. All commands use Hexadecimal or HEX values. In descriptive text these are indicated by preceding the value with a **0x**. Zero-based values are also used in certain areas and are noted as such. This means that a value of **0x00 = 1, 0x01 = 2, and 0x02 = 3** etc...Throughout this document all bytes within message packets not in bold must be referenced exactly as they appear.

## 2 Overview

Russound controllers use a comprehensive communications protocol called **RNET™** which has been extended to the RS-232 port. Through this port, virtually all aspects of the device operation can be performed. This document provides detailed descriptions of messages required to perform basic device operation, as well as instructions on how to interpret display feedback messages.

## 3 COM Port

### 3.1 COM Settings

- 19200 baud rate
- 1 Start bit
- 1 Stop bit
- No flow control
- No parity

### 3.2 Connector Type / Pin-out

**Connector:** Female DB-9

- Pin 1: NC
- Pin 2: Transmit
- Pin 3: Receive
- Pin 4: NC
- Pin 5: Ground
- Pin 6: NC
- Pin 7: NC
- Pin 8: NC
- Pin 9: NC



## 4 RNET™ Message Packet Format

Header				Body	Trailer	
0xF0	Target Device ID	Source Device ID	Type	Body	Checksum	0xF7

Every RNET™ message has a consistent format. There are three major components; the Message Header, Message Body and Message Trailer. Each of these is explained here in some detail.

There are several special characters used in this protocol. The MSB (Most Significant Bit – far left bit of an 8-bit byte – e.g., 0b00010001) of all bytes within the message body of an RNET™ packet are low (0), except for these special characters. These special characters are the “**Start of Message Character**”, the “**End of Message Character**”, and the “**Invert Character**”, which are explained within this document.

### 4.1 Message Header

Each message consists of a “Message Header” which is compiled of a Start of Message Character, Target Device ID, Source Device ID, and the Message Type.

#### 4.1.1 Start of Message Character

0xF0 is the special HEX value that indicates the beginning of a new message.

#### 4.1.2 Target Device ID

The Target Device ID defines to which device we are sending the message. Every device on an RNET™ system has a unique "Device ID" that allows messages to be sent to it. Each Device ID consists of a Controller ID, a Zone (Port) ID and a Keypad ID. In the case of a Controller with zone keypads, the purpose of each Device ID field is apparent.

##### 4.1.2.1 Target Controller ID

On power up, the Controller assigns its Controller ID and a Zone ID to all keypads connected to it. The Controller ID is set in the Controllers “Setup Menu” using 1 based numbering but in the Device ID it is Zero-based (0x00 = 1, 0x01 = 2, 0x02 = 3, etc...). All systems have a controller 0x00 (the Root Controller) with additional controllers added (and numbered) as needed. A value of 0x7F can be used to send messages to all devices in the system.

The Russound RNET™ system provides support for up to 6 connected controllers for a maximum of 36 separate zones. When a multi-controller system is configured, each controller is given a unique controller ID through the programming procedure. All of the controllers are linked together onto a common RNET™ bus, so any messages sent to the RS232 port of controller 1 will be available to all controllers and all keypads in the system.

All of the messages described in this document can be sent to any of the controllers in the system by simply changing the Target Controller ID to match the controller you would like to send the message to.

The following examples show the Volume Up command being sent to the same zone (Zone 1) but on different controllers using Keypad Event messages:

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21
Value	F0	00	00	7F	00	01	70	05	02	02	00	00	7F	00	00	00	00	00	01	7C	F7

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21
Value	F0	01	00	7F	00	01	70	05	02	02	00	00	7F	00	00	00	00	00	01	7D	F7

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21
Value	F0	05	00	7F	00	01	70	05	02	02	00	00	7F	00	00	00	00	00	01	01	F7

Byte #2 shows the Controller ID (Zero Based) that the message is being sent to.

**NOTE:** Remember to recalculate the checksum or the message will be rejected by the controller.

#### 4.1.2.2 Target Zone (Port) ID

Zone ID defines the zone for a particular device. For keypads, this defines which zone port on the Controllers rear panel that the keypad is connected to. The following special Zone ID values have been defined:

Here is a list of special Target Zone (Port) ID values:

Value (Hex)	Description
7F	Reserved
7E	Controller Link
7D	Peripheral Device (Internal Tuner, ST2-XM, etc...)
7C	Trace

Aside from these values and those for the actual ports on the back of a controller, **0x00 – 0x03** for 4 zone controllers and **0x00 – 0x05** for 6 zone controllers, and **0x7D** for a Peripheral Device, any value can be used for the Zone ID field.

#### 4.1.2.3 Target Keypad ID

Keypad ID identifies particular Keypads sharing a single zone on the controller or the Source Number of an Internal Tuner (AM/FM or XM for CAM only) when the Zone ID is set as Peripheral. For keypads, these are numbered **0x00 – 0x05**. For Peripheral Tuners, these are also numbered **0x00 – 0x05**. The following values have specific meaning in the system:

Value (Hex)	Description
7F	The Controller Itself

7E	Reserved
7D	Targets all Keypads on a particular zone or all Sources for connected Peripheral Devices
7C	A special ID used by Keypads when they are requesting an ID (Keypad ID) from the Controller
79	This message is a Source Broadcast Display Feedback message

All other keypad IDs have not been formally assigned so they can be used as needed.

### 4.1.3 Source Device ID

The “Source” Device ID is the identification of the device that is sending the message. For external devices controlling the system, like an automation and control system, these can be any value that is a unique value among devices attached to the system. The recommend Device ID for external control systems is **Controller ID: 0x00, Zone ID: 0x00, and Keypad ID: 0x70**.

#### 4.1.3.1 Source Controller ID

For 3<sup>rd</sup> party devices, this should be set to a value of ‘**0x00**’.

#### 4.1.3.2 Source Zone (Port) ID

For 3<sup>rd</sup> party devices, this should be set to a unique value among devices attached to the system.

#### 4.1.3.3 Source Keypad ID

The recommend Keypad ID for external control systems is **0x70**, which is a Keypad ID other than those used in the system.

### 4.1.4 Message Type

This value defines the type of message that is being sent. The most important Message Types are as follows:

Value (Hex)	Message Type	Description
00	Set Data	Sets a parameter’s value
01	Request Data	Requests a parameter’s value
02	Handshake	Acknowledges a data send
05	Event	Triggers a system response that may set a parameter value, update displays, etc...

In some cases, setting parameter values can be done in two ways. A **Set Data** message can be sent directly to the parameter, or an **Event** message can be sent to trigger the Controller to set the value instead. **Event** messages are a little easier to use, and may trigger other desired results (such as updating Keypad displays, updating related parameters, etc...) where a **Set Data** message may not. Because of this, this document describes using **Event** messages to set parameter values where it is most desirable.

## 4.2 Message Body

The message body contains specific data which varies in value and byte count depending on the particular **Message Type** being sent. Refer to the particular messages.

### 4.2.1 The Invert Character

The **Invert Character** is used in special cases as part of the Message Body. If the data in an **RNET™** message body includes any byte values that have the MSB set to 1 (they have a Hex value greater than **0x7F**) the byte will be rejected as only the lower 7 bits are used to hold data. In order to allow values greater than **0x7F** to be accepted, the byte must first be bitwise inverted (e.g., 10010101 = 01101010), and the special **Invert Character (0xF1)** is inserted just prior to the inverted byte. When an **RNET™** packet is received, the system must detect the **0xF1** invert character. The **0xF1** character is then discarded and the following byte is inverted back to its original value (e.g., 01101010 = 10010101).

#### Invert Character Usage Example:

Sent message with inverted character:

Value (Hex)	Notes
F0	Start of message character
00	
67	
7C	
F1	Special <b>Invert Character</b>
6A	Inverted Character (actual value 0x95)
34	Checksum
F7	End of message character

Received message after re-inverting character:

Value (Hex)	Notes
F0	Start of message character
00	
67	
7C	
95	After re-inversion
XX	Checksum (Discarded)

F7	End of message character
----	--------------------------

### 4.2.2 Event Messages

Event Messages trigger a system response that may set a parameter value, update displays, etc...

**Event Messages** are a little easier to use than Data Messages and may trigger other desired results (such as updating Keypad displays, updating related parameters, etc...) where a **Set Data** message may not. Because of this, this document describes using **Event Messages** to set parameter values where it is most desirable. An **Event Message** Type consists of an Event ID, Event Timestamp, Event Data, and the Event Priority.

### 4.2.3 Data Messages

A **Set Data** message can be sent directly to the parameter to set a parameter's value.

## 4.3 Message Trailer

The Message Trailer consists of the **Checksum** and **End of Message Character**. The **Checksum** value changes and needs to be re-calculated whenever any one of the preceding characters in the message is changed. The **Checksum** is always followed by the **End of Message Character**.

### 4.3.1 Checksum

All messages include a **Checksum** that helps protect the integrity of the message. The **Checksum** is a single byte that can be calculated using the following formula (see example below):

*Checksum Calculation Example:*

Value (Hex)	Notes
F0	Start of Message Character
00	
67	
7C	
F1	
0F	
<b>59</b>	<b>Checksum</b>
F7	End of Message Character

**Step #1** - Add the HEX value of every byte in the message that precedes the Checksum:

*Example* -  $0xF0 + 0x00 + 0x67 + 0x7C + 0xF1 + 0x0F = 0x02D3$

**Step #2** - Count the number of bytes which precede the Checksum and convert that value from DEC to HEX (byte count). Add the byte count in HEX to the previously calculated sum of bytes:

*Example* -  $0x02D3 + 6$  (6 = **Decimal value byte count**) =  $0x02D9$

**Step #3** - This value is then **AND**-ed with the HEX value 0x007F (7F is the highest BIN value for 7 bits = 1111111). The **Checksum** itself and the **End of Message Character** are not included in the calculation. Only the low 7 bits are used so overflow is discarded:

*Example* - **0x02D9 AND 0x007F = 0x59 = Checksum**

### **4.3.2 End of Message Character**

The **End of Message Character (0xF7)** is the special HEX value that indicates the end of the message.

## 5 Buttons and Keycodes

This section describes how to send various events associated with the **Buttons** found on the keypads and/or the IR remote

The method for transmitting these button events falls into two categories:

**-Keypad Events:** The Keypad Events are the events that the keypad is capable of sending.

**-Source Control Events:** All others (Source Control Events) are only available via the IR Remote.

**Note:** all values are in *HEX*.

### 5.1 Keypad Events

Here is a list of UNO Keypad Event values and a description of which buttons they apply to:

Value (Hex)	Description
64	Setup Button
67	Previous
68	Next
69	Plus
6A	Minus
6B	Source (source toggle button)
6C	Power
6D	Stop
6E	Pause
6F	Favorite 1
70	Favorite 2
73	Play
7F	Volume Up
80	Volume Down (because this value is > 7F, the special F1 character must be used)

Here are some examples of some Keypad Events:

#### Zone 1, Volume Up

```
F0 00 00 7F 00 00 70 05 02 02 00 00 7F 00 00 00 00 00 01 7B F7
```

#### Zone 2, Play

```
F0 00 00 7F 00 01 70 05 02 02 00 00 73 00 00 00 00 00 01 70 F7
```

#### Zone 3, Favorite 1

```
F0 00 00 7F 00 02 70 05 02 02 00 00 6F 00 00 00 00 00 01 6D F7
```

Here is a break out of the **Zone1, Volume Up** message (using above example of Keypad Event)

<b>Value</b>	<b>Field</b>	<b>Description</b>
F0	Start of Message	
00	Target Controller ID	Controller 1
00	Target Zone ID	
7F	Target Keypad ID	The Controller itself
00	Source Controller ID	
<b>00</b>	<b>Source Zone ID</b>	<b>Zone affected</b>
70	Source Keypad ID	Arbitrary Keypad ID (not otherwise used by the system)
05	Message Type	Event Message
02	Target Path, Num Levels	
02	Target Path, Level 1	Root Menu
00	Target Path, Level 2	Run Menu
00	Source Path, Num Levels	No Source Path is used
<b>7F</b>	<b>Event ID Lo Byte</b>	<b>Volume Up</b>
00	Event ID Hi Byte	
00	Event Timestamp Lo Byte	unused
00	Event Timestamp Hi Byte	unused
00	Event Data Lo Byte	unused
00	Event Data Hi Byte	unused
01	Event Priority	Low Priority (does not generate a handshake)
<b>7B</b>	<b>Checksum</b>	<b>Recalculate when a preceding byte value is changed</b>
F7	End of Message	

## 5.2 Source Control Events

Source Control Events are unique to the System Remote and are all sent using the special “Remote Control Key” Event type with the actual Keypcode passed in as the Data for the Event.

Here is a list of the Source Control Events (Keycodes):

<b>Value (Hex)</b>	<b>Description</b>
01	“1” Button
02	“2” Button
03	“3” Button
04	“4” Button

05	“5” Button
06	“6” Button
07	“7” Button
08	“8” Button
09	“9” Button
0A	“0” Button
0B	Volume Up
0C	Volume Down
0D	Mute (for zone, not source)
0E	Channel Up
0F	Channel Down
10	Power
11	Enter
12	Previous Channel
13	TV/Video
14	TV/VCR
15	A/B
16	TV/DVD
17	TV/LD
18	Input
19	TV/DSS
1A	Play
1B	Stop
1C	Search Forward
1D	Search Rewind
1E	Pause
1F	Record
20	Menu
21	Menu Up
22	Menu Down
23	Menu Left
24	Menu Right
25	Select
26	Exit
27	Display
28	Guide
29	Page Up
2A	Page Down

2B	Disk
2C	Plus 10
2D	Open/Close
2E	Random
2F	Track Forward
30	Track Reverse
31	Surround On/Off
32	Surround Mode
33	Surround Up
34	Surround Down
35	PIP
36	PIP Move
37	PIP Swap
38	Program
39	Sleep
3A	On
3B	Off
3C	11
3D	12
3E	13
3F	14
40	15
41	16
42	Bright
43	Dim
44	Close
45	Open
46	Stop 2
47	AM/FM
48	Cue
49	Disk Up
4A	Disk Down
4B	Info

Here are some examples of some Source Control Events:

**Zone 1, Menu**

F0 00 00 7F 00 <b>00</b> 70 05 02 02 00 00 <b>F1 40</b> 00 00 00 <b>20</b> 00 01 <b>4E</b> F7
---

**Zone 2, Mute**

F0 00 00 7F 00 <b>01</b> 70 05 02 02 00 00 <b>F1 40</b> 00 00 00 <b>0D</b> 00 01 <b>3C</b> F7
---

**Zone 3, Record**

F0 00 00 7F 00 <b>02</b> 70 05 02 02 00 00 <b>F1 40</b> 00 00 00 <b>1F</b> 00 01 <b>49</b> F7
---

Here is a break out of the **Zone1, Menu** message used in the above example:

<b>Value</b>	<b>Field</b>	<b>Description</b>
F0	Start of Message	
00	Target Controller ID	Controller 1
00	Target Zone ID	
7F	Target Keypad ID	The Controller itself
00	Source Controller ID	
<b>00</b>	<b>Source Zone ID</b>	<b>Zone affected</b>
70	Source Keypad ID	Arbitrary Keypad ID (not otherwise used by the system)
05	Message Type	Event Message
02	Target Path, Num Levels	
02	Target Path, Level 1	Root Menu
00	Target Path, Level 2	Run Menu
00	Source Path, Num Levels	No Source Path is used
<b>F1</b>	<b>Invert</b>	<b>Invert the next byte</b>
<b>40</b>	<b>Event ID Lo Byte</b>	<b>40 = 0xBF inverted = Remote Control Key Release</b>
00	Event ID Hi Byte	
00	Event Timestamp Lo Byte	unused
00	Event Timestamp Hi Byte	unused
<b>20</b>	<b>Event Data Lo Byte</b>	<b>Menu (Keycode)</b>
00	Event Data Hi Byte	unused
01	Event Priority	Low Priority (does not generate a handshake)
<b>7B</b>	<b>Checksum</b>	<b>Recalculate when a preceding byte value is changed</b>
F7	End of Message	

## **6 Using Request Messages**

The Request Data message is used to receive parameter data from the Controller. This may be used to receive Zone Power State, Volume Level, etc. When a Request Data message is sent to the Controller, a Set Data message is generated by the Controller and sent back to the Request Message sender. Since the Set Data message is of high priority, an Acknowledge message must be sent back to the Controller to acknowledge it received the Request message. Failure to send the Acknowledge message will result in a system delay of approximately 2.5 seconds. This is due to the Controller trying to re-send the Data.

Data can be requested discretely for each zone parameter, or all of the Zone information can be requested in a single message.

## 7 Zones

This section will provide information in regards to messages that only apply to Zone commands. This will include controlling the Zones as well as sending Request messages to “Get” the State of the Zones. Zero-based values are used for the Zone Numbers (i.e. **0 = 1, 1 = 2, and 2 = 3** etc...)

### 7.1 ON/OFF

The simplest way to explicitly turn a Zone On or turn a Zone Off is by using the discrete Zone On/Off Event. The Event Data fields determine the Zone and On/Off state. This example shows using the Zone On/Off Event message to execute a Zone On command for Zone 1 of Controller 1. Refer to the Buttons section for information on toggling zone On/Off (“Power” command found under Keypad Events).

#### 7.1.1 Set State

Turn a specific Zone ON or OFF using a discrete message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
Value	F0	cc	00	7F	00	00	70	05	02	02	00	00	F1	23	00	##	00	zz	00	01	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

Byte #16 = 0x00 (off) or 0x01(on)

#### 7.1.2 Get State

This is the **Request** message for the On/Off State of the selected Zone.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
Value	F0	cc	00	7F	00	00	70	01	04	02	00	zz	06	00	00	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

The return message would look like the following.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Value	F0	00	00	70	cc	00	7F	00	00	04	02	00	zz	06	00	00	01	00	01	00	##	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

Byte #21 = 0x00 (off) or 0x01(on)

#### 7.1.3 Set All Zones On/Off State

The RNET™ system can be sent a single message to issue an “All On” or “All Off” Event. The Controllers have the ability to enable or disable the All On/All Off state control per zone. See

the Product Manual for instructions on programming each zone for “System On Enable” or “System On Disable”.

Turn All Zones ON or OFF using a discrete message (*all zones enabled in programming*).

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
Value	F0	7E	00	7F	00	00	70	05	02	02	00	00	F1	22	00	00	##	00	00	01	xx	F7

xx = checksum

Byte #17 = 0x00 (all off) or 0x01(all on)

## 7.2 Source Select

The simplest way to explicitly select a Source per Zone is by using the discrete Source Select Event. The Event Data fields determine the Source being selected. Refer to the Buttons section for information on stepping through Sources (“Source Toggle” command found under Keypad Events). Zero-based values are used for the Source Numbers (i.e. 0 = 1, 1 = 2, and 2 = 3 etc...)

### 7.2.1 Set Source

Select the Source for a particular zone using a discrete message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
Value	F0	cc	00	7F	00	zz	70	05	02	00	00	00	F1	3E	00	00	00	##	00	01	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

Byte #18 = selected source number -1

### 7.2.2 Get Source

This is the **Request** message for what Source is selected on a particular Zone.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
Value	F0	cc	00	7F	00	00	70	01	04	02	00	zz	02	00	00	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

The return message would look like the following.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Value	F0	00	00	70	cc	00	7F	00	00	04	02	00	zz	02	00	00	01	00	01	00	##	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

Byte #21 = source number -1

### 7.3 Volume Select

The simplest way to explicitly select a Volume level per Zone is by using the discrete Volume Select Event. The Even Timestamp fields determine the Volume Level. The Event Data fields determine the Zone affected by the Volume being selected. Refer to the Buttons section for information on stepping through Volume levels (“Volume Up” and “Volume Down” commands found under UNO Keypad Events). Volume levels displayed on UNO keypads range in value from 0 – 100 in steps of 2 (i.e. 0, 2, 4, 6, etc...). These Volume levels are represented in Decimal when using RS-232 messages ranging in value from 0 – 50 (i.e. 0 = 0, 1 = 2, ... 2 = 4). In the actual Data message the HEX value is used which would range in value from 0x00 – 0x32. This means (0x00 = 0 = 0, 0x01 = 1 = 2, 0x02 = 2 = 4 ... 0x32 = 50 = 100)

#### 7.3.1 Set Volume

Select the Volume for a particular zone using a discrete message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
Value	F0	cc	00	7F	00	00	70	05	02	02	00	00	F1	21	00	##	00	zz	00	01	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

Byte #16 = volume level (0x00 - 0x32, 0x00 = 0 Displayed ... 0x32 = 100 Displayed)

#### 7.3.2 Get Volume

This is the Request message for what Volume level is selected on a particular Zone.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
Value	F0	cc	00	7F	00	00	70	01	04	02	00	zz	01	00	00	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

The return message would look like the following.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Value	F0	00	00	70	cc	00	7F	00	00	04	02	00	zz	01	00	00	01	00	01	00	##	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

Byte #21 = Volume Level -1

## 7.4 Bass

Bass levels displayed on keypads range in value from -10 through +10. These Bass levels are represented in Decimal when using RS-232 messages ranging in value from 0 - 20. In the actual Data message the HEX value is used which would range in value from 0x00 – 0x14. This means (0x00 = 0 = -10, 0x01 = 1 = -9, 0x02 = 2 = -8 ... 0x14 = 20 = +10).

**NOTE:** The keypad displays will not automatically update for this change.

### 7.4.1 Bass Up/Bass Down

The following example shows the Bass level being increased or decreased.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	cc	00	7F	00	00	70	05	05	02	00	zz	00	00	00	##	00	00	00	00	00	01	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

**Byte #16** = button event (Plus = 0x69 = Increase, Minus = 0x6A = Decrease)

### 7.4.2 Set Bass

Select the Bass level for a particular zone using a discrete message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	cc	00	7F	00	00	70	00	05	02	00	zz	00	00	00	00	00	01	00	01	00	##	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

**Byte #22** = Bass level (0x00 = -10 ... 0x0A = Flat ... 0x14 = +10)

### 7.4.3 Get Bass

The current Bass setting for a particular zone can be obtained by using the following message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
Value	F0	cc	00	7F	00	00	70	01	05	02	00	zz	00	00	00	00	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

The return message would look like the following.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	00	00	70	cc	00	7F	00	00	05	02	00	zz	00	00	00	00	01	00	01	00	##	xx	7F

cc = controller number -1

zz = zone number -1

xx = checksum

**Byte #22** = Bass level (0x00 = -10 ... 0x0A = Flat ... 0x14 = +10)

## 7.5 Treble

Treble levels displayed on keypads range in value from -10 through +10. These Treble levels are represented in Decimal when using RS-232 messages ranging in value from 0 - 20. In the actual Data message the HEX value is used which would range in value from 0x00 – 0x14. This means (0x00 = 0 = -10, 0x01 = 1 = -9, 0x02 = 2 = -8 ... 0x14 = 20 = +10).

**NOTE:** The keypad displays will not automatically update for this change.

### 7.5.1 Treble Up/Treble Down

The following example shows the Treble level being increased or decreased.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	cc	00	7F	00	00	70	05	05	02	00	zz	00	01	00	##	00	00	00	00	00	01	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

**Byte #16** = button event (Plus = 0x69 = Increase, Minus = 0x6A = Decrease)

### 7.5.2 Set Treble

Select the Treble level for a particular zone using a discrete message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	cc	00	7F	00	00	70	00	05	02	00	zz	00	01	00	00	00	01	00	01	00	##	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

**Byte #22** = Treble level (0x00 = -10 ... 0x0A = Flat ... 0x14 = +10)

### 7.5.3 Get Treble

The current Treble setting for a particular zone can be obtained by using the following message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
Value	F0	cc	00	7F	00	00	70	01	05	02	00	zz	00	01	00	00	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

The return message would look like the following.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	00	00	70	cc	00	7F	00	00	05	02	00	zz	00	01	00	00	01	00	01	00	##	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

**Byte #22** = Treble level (0x00 = -10 ... 0x0A = Flat ... 0x14 = +10)

## 7.6 Loudness

Loudness is displayed on keypads as “On” or “Off”. Loudness can be toggled On or Off with a Plus or Minus command. There can also be a discrete On or Off command selected.

**NOTE:** *The keypad displays will not automatically update for this change.*

### 7.6.1 Loudness Toggle On/Off

The following example shows how to toggle the Loudness “On” and “Off” for a particular Zone.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	cc	00	7F	00	00	70	05	05	02	00	zz	00	02	00	##	00	00	00	00	00	01	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

**Byte #16** = button event (PLUS = 0x69 = On/Off toggle) or (MINUS = 0x6A = On/Off toggle)

### 7.6.2 Set Loudness

Turn Loudness On or Off for a particular zone using a discrete message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	cc	00	7F	00	00	70	00	05	02	00	zz	00	02	00	00	00	01	00	01	00	##	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

**Byte #22** = Loudness setting (0x00 = OFF, 0x01 = ON )

### 7.6.3 Get Loudness

The current Loudness setting for a particular zone can be obtained by using the following message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
Value	F0	cc	00	7F	00	00	70	01	05	02	00	zz	00	02	00	00	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

The return message would look like the following.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	00	00	70	cc	00	7F	00	00	05	02	00	zz	00	02	00	00	01	00	01	00	##	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

**Byte #22** = Loudness setting (0x00 = OFF, 0x01 = ON )

## 7.7 Balance

Balance levels displayed on keypads range in value from “Left 10” to “Center” to “Right 10”. These Balance levels are represented in Decimal when using RS-232 messages ranging in value from 0 - 20. In the actual Data message the HEX value is used which would range in value from 0x00 – 0x14. This means (**0x00 = 0 = Left 10 ... 0x0A = 10 = Center ... 0x14 = 20 = Right 10**).

**NOTE:** *The keypad displays will not automatically update for this change.*

### 7.7.1 Balance Left or Balance Right

The following example shows the Balance level being drawn More Left or More Right.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	cc	00	7F	00	00	70	05	05	02	00	zz	00	03	00	##	00	00	00	00	00	01	xx	F7

**cc** = controller number -1

**zz** = zone number -1

**xx** = checksum

**Byte #16** = button event (Plus = 0x69 = More Left, Minus = 0x6A = More Right)

### 7.7.2 Set Balance

Select the Balance level for a particular zone using a discrete message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	cc	00	7F	00	00	70	00	05	02	00	zz	00	03	00	00	00	01	00	01	00	##	xx	F7

**cc** = controller number -1

**zz** = zone number -1

**xx** = checksum

**Byte #22** = Balance level (0x00 = More Left ... 0x0A = Center ... 0x14 = More Right)

### 7.7.3 Get Balance

The current Balance setting for a particular zone can be obtained using the following message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
Value	F0	cc	00	7F	00	00	70	01	05	02	00	zz	00	03	00	00	xx	F7

**cc** = controller number -1

**zz** = zone number -1

**xx** = checksum

The return message would look like the following.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	00	00	70	cc	00	7F	00	00	05	02	00	zz	00	03	00	00	01	00	01	00	##	xx	F7

**cc** = controller number -1

**zz** = zone number -1

**xx** = checksum

**Byte #22** = Balance level (0x00 = More Left ... 0x0A = Center ... 0x14 = More Right)

## 7.8 Turn On Volume

Turn On Volume levels displayed on keypads range in value from 0 – 100 in steps of 2 (i.e. 0, 2, 4 ... 100). These Turn On Volume levels are represented in Decimal when using RS-232 messages ranging in value from 0 - 50. In the actual Data message the HEX value is used which would range in value from 0x00 – 0x32. This means (**0x00 = 0 = 0, 0x01 = 1 = 2, 0x02 = 2 = 4 ... 0x32 = 50 = 100**)

**NOTE:** *The keypad displays will not automatically update for this change.*

### 7.8.1 Increase or Decrease Turn On Volume

The following example shows the Turn On Volume level being increased or decreased.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	cc	00	7F	00	00	70	05	05	02	00	zz	00	04	00	bb	00	00	00	00	00	01	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

### 7.8.2 Set Turn On Volume

Select the Turn On Volume level for a particular zone using a discrete message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	cc	00	7F	00	00	70	00	05	02	00	zz	00	04	00	00	00	01	00	01	00	##	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

**Byte #22** = Turn On Volume level (0x00 - 0x32, 0x00 = 0 ... 0x32 = 100)

### 7.8.3 Get Turn On Volume

The current Turn On Volume for a particular zone can be obtained using the following message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
Value	F0	cc	00	7F	00	00	70	01	05	02	00	zz	00	04	00	00	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

The return message would look like the following.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	00	00	70	cc	00	7F	00	00	04	02	00	zz	01	00	00	00	01	00	01	00	##	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

**Byte #22** = Turn On Volume level (0x00 - 0x32, 0x00 = 0 ... 0x32 = 100)

## 7.9 Background Color

Background Color is displayed on keypads as “Amber”, “Green”, or “Off”. The Background Color can be toggled through these selections with a Plus or Minus command. There can also be a discrete command selected for each choice.

**NOTE:** *The keypad displays WILL automatically update for this selection.*

### 7.9.1 Background Color Off/Amber/Green toggle

The following example shows how to toggle the Background Color for a particular Zone.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	00	00	7F	00	00	70	05	05	02	00	<b>zz</b>	00	05	00	<b>##</b>	00	00	00	00	00	01	<b>xx</b>	F7

**cc** = controller number -1

**zz** = zone number -1

**xx** = checksum

**Byte #16** = button event (Plus = 0x69 = Off/Color toggle) or (Minus = 0x6A = Off/Color toggle)

### 7.9.2 Set Background Color

Select the Background Color for a particular zone using a discrete message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	00	00	7F	00	00	70	00	05	02	00	<b>zz</b>	00	05	00	00	00	01	00	01	00	<b>##</b>	<b>xx</b>	F7

**cc** = controller number -1

**zz** = zone number -1

**xx** = checksum

**Byte #22** = Background Color (0x00 = Off, 0x01 = Amber, 0x02 = Green)

### 7.9.3 Get Background Color

The current Background Color for a particular zone can be obtained using the following message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
Value	F0	<b>cc</b>	00	7F	00	00	70	01	05	02	00	<b>zz</b>	00	05	00	00	<b>xx</b>	F7

**cc** = controller number -1

**zz** = zone number -1

**xx** = checksum

The return message would look like the following.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	00	00	70	<b>cc</b>	00	7F	00	00	05	02	00	<b>zz</b>	00	05	00	00	01	00	01	00	<b>##</b>	<b>xx</b>	F7

**cc** = controller number -1

**zz** = zone number -1

**xx** = checksum

**Byte #22** = Background Color (0x00 = Off, 0x01 = Amber, 0x02 = Green)

## 7.10 Do Not Disturb

Do Not Disturb is displayed on keypads as “On” or “Off”. DND can be toggled On or Off with a Plus or Minus command. There can also be a discrete On or Off command selected.

### 7.10.1 Do Not Disturb On/Off Toggle

The following example shows how to toggle Do Not Disturb “On” and “Off” for a particular Zone.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	00	00	7F	00	00	70	05	05	02	00	zz	00	06	00	##	00	00	00	00	00	01	xx	F7

**cc** = controller number -1

**zz** = zone number -1

**xx** = checksum

**Byte #16** = button event (Plus = 0x69 = On/Off toggle) or (Minus = 0x6A = On/Off toggle)

### 7.10.2 Set Do Not Disturb

Turn DND On or Off for a particular zone using a discrete message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	00	00	7F	00	00	70	00	05	02	00	zz	00	06	00	00	00	01	00	01	00	##	xx	F7

**cc** = controller number -1

**zz** = zone number -1

**xx** = checksum

**Byte #22** = Do Not Disturb setting (0x00 = OFF, 0x01 = ON )

### 7.10.3 Get Do Not Disturb

The current DND setting for a particular zone can be obtained by using the following message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
Value	F0	cc	00	7F	00	00	70	01	05	02	00	zz	00	06	00	00	xx	F7

**cc** = controller number -1

**zz** = zone number -1

**xx** = checksum

The return message would look like the following.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	00	00	70	cc	00	7F	00	00	05	02	00	zz	00	06	00	00	01	00	01	00	##	xx	F7

**cc** = controller number -1

**zz** = zone number -1

**xx** = checksum

**Byte #22** = Do Not Disturb setting (0x00 = OFF, 0x01 = ON )

## 7.11 Party Mode

Party Mode is displayed on keypads as “On”, “Off”, or “Master”. Party Mode can be toggled to “On” or “Master” with the Plus command. The Minus command will toggle Party Mode “Off”. There can also be a discrete On, Off, or Master command sent.

### 7.11.1 Party Mode On, Party Mode Master, and Party Mode Off

**NOTE:** *If Party Mode is Off, then “Plus” will issue a “Master” command. If a Zone is turned on while the rest of the system has Party Mode On and a different Zone is the Master, then “Plus” from a non-active Zone will issue an “On” command first and then a “Master” command second. If Party Mode is On and a different Zone is Master, then “Plus” from an active zone will issue a “Master” command. Minus will always issue an “Off” command.*

The following example shows how to toggle Party Mode for a particular Zone.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	00	00	7F	00	00	70	05	05	02	00	zz	00	07	00	##	00	00	00	00	00	01	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

Byte #16 = button event (Plus = 0x69 = On/Off toggle) or (Minus = 0x6A = On/Off toggle)

### 7.11.2 Set Party Mode

Select Party Mode “Master”, “On”, or “Off” for a particular zone using a discrete message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	00	00	7F	00	00	70	00	05	02	00	zz	00	07	00	00	00	01	00	01	00	##	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

Byte #22 = Party Mode setting (0x00 = OFF, 0x01 = ON, 0x02 = Master)

### 7.11.3 Get Party Mode

The current Party Mode state for a particular zone can be obtained using the following message.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
Value	F0	cc	00	7F	00	00	70	01	05	02	00	zz	00	07	00	00	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

The return message would look like the following.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	00	00	70	cc	00	7F	00	00	05	02	00	zz	00	07	00	00	01	00	01	00	##	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

Byte #22 = Party Mode setting (0x00 = OFF, 0x01 = ON, 0x02 = Master)

## 7.12 Get All Zone info

As stated previously, a message can be used to request all of a particular Zone's parameter values at once. This can be very useful for updating panel displays. The following is an example of how to request Zone information for a particular Zone and what the return message would look like.

### 7.12.1 Get State

This is the **Request** message for the parameter values of the selected Zone.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
Value	F0	cc	00	7F	00	00	70	01	04	02	00	zz	07	00	00	xx	F7

cc = controller number -1

zz = zone number -1

xx = checksum

The return message would look like the following.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Value	F0	00	00	70	cc	00	7F	00	00	04	02	00	zz	07	00	00	01	00	0C	00	##	##	##
Byte #	24	25	26	27	28	29	30	31	32	33	34												
Value	##	##	##	##	##	##	##	##	00	xx	F7												

cc = controller number -1

zz = zone number -1

xx = checksum

The parameter values are depicted in bytes 21 – 31. These values will change depending on the state of the selected Zone. The above example shows the parameter values for a Zone configured and being used as follows:

**Byte #21** = Current Zone On/Off state (0x00 = OFF or 0x01 = ON)

**Byte #22** = Current Source selected -1

**Byte #23** = Current Volume level (0x00 - 0x32, 0x00 = 0 Displayed ... 0x32 = 100 Displayed)

**Byte #24** = Current Bass level (0x00 = -10 ... 0x0A = Flat ... 0x14 = +10)

**Byte #25** = Current Treble level (0x00 = -10 ... 0x0A = Flat ... 0x14 = +10)

**Byte #26** = Current Loudness (0x00 = OFF, 0x01 = ON )

**Byte #27** = Current Balance level (0x00 = More Left ... 0x0A = Center ... 0x14 = More Right)

**Byte #28** = Current System On state (0x00 = All Zones Off, 0x01 = Any Zone is On)

**Byte #29** = Current Shared Source (0x00 = Not Shared 0x01 = Shared with another Zone)

**Byte #30** = Current Party Mode state (0x00 = OFF, 0x01 = ON, 0x02 = Master)\*

**Byte #31** = Current Do Not Disturb state (0x00 = OFF, 0x01 = ON )\*

\*NOTE: Unsupported Features, information not available for CAS44 and CAA66 controllers

## 8 Displaying a String

Since the keypad contains a text display, we've provided a message that will allow you to send text messages to All Keypads simultaneously or a Specific Keypad individually.

“**Alignment**” – When sending a message to display text on a Keypad the first Data byte sets your Alignment (**0x00** = Centered, **0x01** = Left justified).

“**Flash Time**” – Messages can be displayed constant or they can be flashed on the display for a brief time. When sending a message to display text on a Keypad the second and third Data bytes set the Flash Time. Flash Time defines how long the string is displayed. This is measured in **10ms** increments with a value of **0x00** being **constant**.

“**Null character**” – A value of **0x00** used as a Data byte will be a text character of Null. A Null text character is always used after the last text character in the display string. With a 12 character text message you would use a Null character as the 13<sup>th</sup> text character. A Null character is also used for each unused text character at the end of the text display message if the maximum number of Data bytes are not all used.

### 8.1 On All Keypads

The following example shows how to display a text message on All Keypads (or other devices with a text display) in the system.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	<b>7F</b>	<b>00</b>	<b>00</b>	00	00	70	00	02	01	01	00	00	00	01	00	10	00	##	##	##	##	##	##
Byte #	25	26	27	28	29	30	31	32	33	34	35	36												
Value	##	##	##	##	##	##	##	##	##	##	##	xx	F7											

**cc** = Controller Number -1 (0x7F = All Devices = All Keypads)

**zz** = Zone Number -1

**kk** = Keypad Number -1

**xx** = Checksum

**Byte #19** = Alignment (0x00 = Centered, 0x01 = Left justified)

**Byte #20** = Low Byte of Flash Time

**Byte #21** = High Byte of Flash Time

**Byte #22 – #34** = ASCII text characters (Section 11 ASCII Character Set)

### 8.2 On A Specific Keypad

The following example shows how to display a text message on a Specific Keypad in the system. This is accomplished by setting the Target Device ID for the particular keypad in question.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	<b>cc</b>	<b>zz</b>	<b>kk</b>	00	00	70	00	02	01	01	00	00	00	01	00	10	00	##	##	##	##	##	##
Byte #	25	26	27	28	29	30	31	32	33	34	35	36												
Value	##	##	##	##	##	##	##	##	##	##	##	xx	F7											

**cc** = Controller Number -1

**zz** = Zone Number -1

**kk** = Keypad Number -1

**xx** = Checksum



**Byte #19** = Alignment (0x00 = Centered, 0x01 = Left justified)  
**Byte #20** = Low Byte of Flash Time  
**Byte #21** = High Byte of Flash Time  
**Byte #22 – #34** = ASCII text characters (Section 11 ASCII Character Set)

## 9 Display Messages

The following section describes how to read Display Messages. These include Direct Display Feedback messages, Source Broadcast Display Feedback messages, and Multi-Field Broadcast Display Feedback messages.

**NOTE:** *In order to fully support the display capabilities, Direct Display feedback messages, Source Broadcast Feedback messages and Multi-Field Broadcast Messages, should be supported. (Multi-Field Broadcast messages are only used with XM.)*

### 9.1 Reading Direct Display Feedback

This section describes how to read Direct Display Feedback Messages. These Feedback messages are usually sent in direct response to a received command (e.g., If the current frequency of a Russound tuner is “102.7 MHz FM”, sending the “Frequency Up” command will trigger the Tuner to send a Display message back to the sender to update the frequency Display to "102.9 MHz FM"). The Direct Display Feedback message is sent directly to the Target Device ID of the message sender. The message can be displayed for a constant amount of time, or a "Flash" display with a specified length of time (Flash Time is in increments of 10ms).

**NOTE:** *It is possible that some display messages will include the special "Invert" control character (0xF1).*

**NOTE:** *Some of the other bytes within this message may vary. Only the ones necessary to interpret the message are highlighted.*

**NOTE:** *This message shows a text payload of 16 characters. Some devices may have a text payload of 12 characters.*

This is what the Direct Display Feedback message would look like using the above example.

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	<b>00</b>	<b>00</b>	<b>70</b>	00	7D	00	00	02	01	01	02	01	01	00	00	01	00	<b>14</b>	00	01	<b>00</b>	<b>00</b>	<b>31</b>
Byte #	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42						
Value	<b>30</b>	<b>32</b>	<b>2E</b>	<b>39</b>	<b>20</b>	<b>4D</b>	<b>48</b>	<b>7A</b>	<b>20</b>	<b>46</b>	<b>4D</b>	<b>00</b>	<b>00</b>	<b>00</b>	<b>00</b>	<b>00</b>	<b>7F</b>	F7						

**Byte #2 – #4** = Target Device ID (This message should be displayed if the target Device ID matches the Device ID of your device.)

**Byte #19** = Overall Payload Size

**Byte #22** = Flash Time low byte (Flash time is in 10ms increments, **0x00** = Constant)

**Byte #23** = Flash Time high byte

**Byte #24 – #40** = Text (“102.9 MHz FM” used in above example)

**Byte #41** = Calculated Checksum

## 9.2 Reading Source Broadcast Display Feedback

This section describes how to read Source Broadcast Display Feedback messages. These Feedback messages are sent to update all devices monitoring a given Source's status. These messages may be sent as a direct result of a sent command or as a general update. The Display Feedback message is sent with the source number of the Source attached. The attached source number indicates which Source the update is intended. The message can be displayed for a constant amount of time, or a "Flash" display with a specified length of time (Flash Time is in increments of 10ms).

**NOTE:** *It is possible that some display messages will include the special "Invert" control character (0xF1).*

**NOTE:** *Some of the other bytes within this message may vary. Only the ones necessary to interpret the message are highlighted.*

**NOTE:** *This message shows a text payload of 16 characters. Some devices may have a text payload of 12 characters.*

This example shows a Source Broadcast Display Feedback message with text "102.9 MHz FM".

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	7D	00	<b>79</b>	00	7D	00	00	02	01	01	02	01	01	00	00	01	00	<b>14</b>	00	<b>10</b>	<b>00</b>	<b>00</b>	<b>31</b>
Byte #	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42						
Value	<b>30</b>	<b>32</b>	<b>2E</b>	<b>39</b>	<b>20</b>	<b>4D</b>	<b>48</b>	<b>7A</b>	<b>20</b>	<b>46</b>	<b>4D</b>	<b>00</b>	<b>00</b>	<b>00</b>	<b>00</b>	<b>00</b>	<b>14</b>	F7						

**Byte #4** = Target Keypad ID (**NOTE:** A value of **0x79** in the Target Keypad ID field indicates that this message is a Source Broadcast Display Feedback message.)

**Byte #19** = Overall Payload Size

**Byte #21** = Message type and Source Number = (0x10 (Source Broadcast Display Type) bit-wise **OR**-ed with the source number (e.g. source 1 = 0x10, source 3 = 0x12))

**Byte #22** = Flash Time low byte (Flash time is in 10ms increments, **0x00** = Constant)

**Byte #23** = Flash Time high byte

**Bytes #24 – #40** = Text ("102.9 MHz FM")

**Byte #41** = Calculated Checksum

### 9.3 Reading Multi-Field Broadcast Display Feedback Messages

Multi-Field Broadcast Display Feedback messages are sent to update all devices monitoring the Source's status. These Feedback messages are sent to update all devices monitoring a given Source's status. These messages may be sent as a direct result of a sent command or as a general update. The Display Feedback message is sent with the source number of the Source attached. A "Field ID" is included with the message to indicate which item is being updated (see table below). The message can be displayed for a constant amount of time, or a "Flash" display with a specified length of time (Flash Time is in increments of 10ms).

This example shows a Multi-Field Broadcast Display Feedback message text "49: Fine Tuning".

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Value	F0	7D	00	<b>79</b>	00	7D	00	00	02	01	01	02	01	01	00	00	01	00	<b>14</b>	00	<b>20</b>	<b>07</b>	1C	<b>34</b>
Byte #	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42						
Value	<b>39</b>	<b>3A</b>	<b>46</b>	<b>69</b>	<b>6E</b>	<b>65</b>	<b>54</b>	<b>75</b>	<b>6E</b>	<b>69</b>	<b>6E</b>	<b>67</b>	<b>00</b>	<b>00</b>	<b>00</b>	<b>00</b>	<b>09</b>	F7						

**Byte #4** = Target Keypad ID (**NOTE:** A value of **0x79** in the Target Keypad ID field indicates that this message is a Source Broadcast Display Feedback message.)

**Byte #19** = Overall Payload Size

**Byte #21** = Message type and Source Number = (0x20 (Multi-Field Display Type) bit-wise OR-ed with the source number (e.g., source 1 = 0x20, source 3 = 0x22.))

**Byte #22** = Field ID bit and Flash Bit = (bits 0 – 6 = Field Id (i.e., 0x07 = 7 = Channel Name), Bit 7 – Ignore. Invert control character (0xF1) will be inserted before this byte if Bit 7 is set.

**Bytes #24 – #40** = Text ("49: Fine Tuning")

**Byte #41** = Calculated Checksum

## 10 Using the Acknowledge Message (Handshaking)

When the controller sends a Return message in response to a Request message, the sender of the Request message must send an Acknowledge message in response to the Return message.

Failure to send the Acknowledge message will result in a system delay of approximately 2.5 seconds while the controller tries to re-send the data. The controller will also send an

Acknowledge message in response to a Set Data message that it is sent. It is not necessary to process the incoming Acknowledge message from the controller.

**NOTE:** A Peripheral Source does not require Handshaking when the keypad ID used to send data is 0x70. If using a keypad ID of 0x70, and therefore no Handshaking, it is best to leave approximately 100ms between messages to ensure that all messages are processed correctly. If Handshaking is desired, it is recommended to use a keypad ID of 0x60. In this case, the Peripheral Source will send an Acknowledge message in response to any high priority event messages sent. Acknowledge messages can be (and normally are) used to trigger the release of any additional messages that may be in the sender's queue.

This example shows sending a Frequency Up (Tune Up) event to a Russound Tuner: *In this case the event priority byte is set to 0x00 (high) and the sender Keypad ID is 0x60. This means that the Internal Tuner will send an Acknowledge message in response.*

Byte #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Value	F0	00	7D	00	00	00	60	05	02	01	00	02	01	00	2F	00	70	00	00	00	00	0C	F7

**Byte #4** = Source Number - 1 (Zero-based)

**Byte #7** = Sender Keypad ID - 0x60 (0x60 indicates that this message requires a handshake message if the event is high priority)

**Byte #15** = Event ID (TUNE UP)

**Byte #17** = Return Keypad Id - 0x70 (This is the keypad ID that the ST2 will send any resulting direct display message to. If this byte is set to 0x70, it will not require you to send a handshake message in response to the display message. If the original Sender keypad ID of 0x60 is used here, you will need to send a handshake message when the direct display message comes back. Failure to send the handshake message will result in a system delay of approximately 2.5 seconds, while the ST2 tries to re-send the data. It is recommended to leave this byte as 0x70.)

**Byte #19** = Source Number - 1 (Zero-based)

**Byte #21** = Event Priority (0 = high, 1 = low)

**Byte #22** = Calculated Checksum

Handshake message returned to sender to acknowledge a high priority event message

Byte #	1	2	3	4	5	6	7	8	9	10	11
Value	F0	00	00	60	00	7D	00	02	06	5E	F7

**Byte #7** = Source Number of Event Recipient - 1 (Zero-based)

**Byte #8** = Message Type (HANDSHAKE)

**Byte #9** = Handshake Type (EVENT HANDSHAKE)

**Byte #10** = Calculated Checksum

## 11 ASCII Character Set to HEX Conversion Chart

ASCII	=	HEX	ASCII	=	HEX	ASCII	=	HEX
Space		20	@		40	`		60
!		21	A		41	a		61
"		22	B		42	b		62
#		23	C		43	c		63
\$		24	D		44	d		64
%		25	E		45	e		65
&		26	F		46	f		66
'		27	G		47	g		67
(		28	H		48	h		68
)		29	I		49	i		69
*		2A	J		4A	j		6A
+		2B	K		4B	k		6B
,		2C	L		4C	l		6C
-		2D	M		4D	m		6D
.		2E	N		4E	n		6E
/		2F	O		4F	o		6F
0		30	P		50	p		70
1		31	Q		51	q		71
2		32	R		52	r		72
3		33	S		53	s		73
4		34	T		54	t		74
5		35	U		55	u		75
6		36	V		56	v		76
7		37	W		57	w		77
8		38	X		58	x		78
9		39	Y		59	y		79
:		3A	Z		5A	z		7A
;		3B	[		5B	{		7B
<		3C	\		5C			7C
=		3D	]		5D	}		7D
>		3E	^		5E	~		7E
?		3F	_		5F	Del		7F

## 12 Russound Controllers RS-232 Hex Code Listing

Russound Controllers RS-232 Hex Code Listing																						
CONTROLLER #1 KEYPAD EVENTS - ZONE POWER ON AND OFF COMMANDS																						
	F0		00	7F	00	00	70	05	02	02	00	00	F1	23	00		00		00	01		F7
Byte Count	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
ZONE 1 ON	F0	00	00	7F	00	00	70	05	02	02	00	00	F1	23	00	01	00	00	01	12	F7	
ZONE 1 OFF	F0	00	00	7F	00	00	70	05	02	02	00	00	F1	23	00	00	00	00	01	11	F7	
ZONE 2 ON	F0	00	00	7F	00	00	70	05	02	02	00	00	F1	23	00	01	00	01	00	01	13	F7
ZONE 2 OFF	F0	00	00	7F	00	00	70	05	02	02	00	00	F1	23	00	00	00	01	00	01	12	F7
ZONE 3 ON	F0	00	00	7F	00	00	70	05	02	02	00	00	F1	23	00	01	00	02	00	01	14	F7
ZONE 3 OFF	F0	00	00	7F	00	00	70	05	02	02	00	00	F1	23	00	00	00	02	00	01	13	F7
ZONE 4 ON	F0	00	00	7F	00	00	70	05	02	02	00	00	F1	23	00	01	00	03	00	01	15	F7
ZONE 4 OFF	F0	00	00	7F	00	00	70	05	02	02	00	00	F1	23	00	00	00	03	00	01	14	F7
ZONE 5 ON	F0	00	00	7F	00	00	70	05	02	02	00	00	F1	23	00	01	00	04	00	01	16	F7
ZONE 5 OFF	F0	00	00	7F	00	00	70	05	02	02	00	00	F1	23	00	00	00	04	00	01	15	F7
ZONE 6 ON	F0	00	00	7F	00	00	70	05	02	02	00	00	F1	23	00	01	00	05	00	01	17	F7
ZONE 6 OFF	F0	00	00	7F	00	00	70	05	02	02	00	00	F1	23	00	00	00	05	00	01	16	F7
CONTROLLER #1 - ALL ON / ALL OFF																						
	F0	7E	00	7F	00	00	70	05	02	02	00	00	F1	22	00	00		00	00	01		F7
Byte Count	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
ALL ON	F0	7E	00	7F	00	00	70	05	02	02	00	00	F1	22	00	00	01	00	00	01	0F	F7
ALL OFF	F0	7E	00	7F	00	00	70	05	02	02	00	00	F1	22	00	00	00	00	00	01	0E	F7
CONTROLLER #1 KEYPAD EVENTS - ZONE VOLUME UP/DOWN COMMANDS																						
	F0	00	00	7F	00		70	05	02	02	00	00		00	00	00	00	01		F7		
Byte Count	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
ZONE 1 VOL UP	F0	00	00	7F	00	00	70	05	02	02	00	00	7F	00	00	00	00	01	7B	F7		
ZONE 1 VOL DN	F0	00	00	7F	00	00	70	05	02	02	00	00	F1	7F	00	00	00	00	01	6D	F7	
ZONE 2 VOL UP	F0	00	00	7F	00	01	70	05	02	02	00	00	7F	00	00	00	00	01	7C	F7		
ZONE 2 VOL DN	F0	00	00	7F	00	01	70	05	02	02	00	00	F1	7F	00	00	00	00	01	6E	F7	
ZONE 3 VOL UP	F0	00	00	7F	00	02	70	05	02	02	00	00	7F	00	00	00	00	01	7D	F7		
ZONE 3 VOL DN	F0	00	00	7F	00	02	70	05	02	02	00	00	F1	7F	00	00	00	00	01	6F	F7	
ZONE 4 VOL UP	F0	00	00	7F	00	03	70	05	02	02	00	00	7F	00	00	00	00	01	7E	F7		
ZONE 4 VOL DN	F0	00	00	7F	00	03	70	05	02	02	00	00	F1	7F	00	00	00	00	01	70	F7	
ZONE 5 VOL UP	F0	00	00	7F	00	04	70	05	02	02	00	00	7F	00	00	00	00	01	7F	F7		
ZONE 5 VOL DN	F0	00	00	7F	00	04	70	05	02	02	00	00	F1	7F	00	00	00	00	01	71	F7	
ZONE 6 VOL UP	F0	00	00	7F	00	05	70	05	02	02	00	00	7F	00	00	00	00	01	00	F7		
ZONE 6 VOL DN	F0	00	00	7F	00	05	70	05	02	02	00	00	F1	7F	00	00	00	00	01	72	F7	

CONTROLLER #1 KEYPAD EVENTS - ZONE PREVIOUS/NEXT & PLUS/MINUS COMMANDS																					
Byte Count	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21
ZONE 1 PREV	F0	00	00	7F	00	00	70	05	02	02	00	00	67	00	00	00	00	00	01	63	F7
ZONE 1 NEXT	F0	00	00	7F	00	00	70	05	02	02	00	00	68	00	00	00	00	00	01	64	F7
ZONE 1 PLUS	F0	00	00	7F	00	00	70	05	02	02	00	00	69	00	00	00	00	00	01	65	F7
ZONE 1 MINUS	F0	00	00	7F	00	00	70	05	02	02	00	00	6A	00	00	00	00	00	01	66	F7
ZONE 2 PREV	F0	00	00	7F	00	01	70	05	02	02	00	00	67	00	00	00	00	00	01	64	F7
ZONE 2 NEXT	F0	00	00	7F	00	01	70	05	02	02	00	00	68	00	00	00	00	00	01	65	F7
ZONE 2 PLUS	F0	00	00	7F	00	01	70	05	02	02	00	00	69	00	00	00	00	00	01	66	F7
ZONE 2 MINUS	F0	00	00	7F	00	01	70	05	02	02	00	00	6A	00	00	00	00	00	01	67	F7
ZONE 3 PREV	F0	00	00	7F	00	02	70	05	02	02	00	00	67	00	00	00	00	00	01	65	F7
ZONE 3 NEXT	F0	00	00	7F	00	02	70	05	02	02	00	00	68	00	00	00	00	00	01	66	F7
ZONE 3 PLUS	F0	00	00	7F	00	02	70	05	02	02	00	00	69	00	00	00	00	00	01	67	F7
ZONE 3 MINUS	F0	00	00	7F	00	02	70	05	02	02	00	00	6A	00	00	00	00	00	01	68	F7
ZONE 4 PREV	F0	00	00	7F	00	03	70	05	02	02	00	00	67	00	00	00	00	00	01	66	F7
ZONE 4 NEXT	F0	00	00	7F	00	03	70	05	02	02	00	00	68	00	00	00	00	00	01	67	F7
ZONE 4 PLUS	F0	00	00	7F	00	03	70	05	02	02	00	00	69	00	00	00	00	00	01	68	F7
ZONE 4 MINUS	F0	00	00	7F	00	03	70	05	02	02	00	00	6A	00	00	00	00	00	01	69	F7
ZONE 5 PREV	F0	00	00	7F	00	04	70	05	02	02	00	00	67	00	00	00	00	00	01	67	F7
ZONE 5 NEXT	F0	00	00	7F	00	04	70	05	02	02	00	00	68	00	00	00	00	00	01	68	F7
ZONE 5 PLUS	F0	00	00	7F	00	04	70	05	02	02	00	00	69	00	00	00	00	00	01	69	F7
ZONE 5 MINUS	F0	00	00	7F	00	04	70	05	02	02	00	00	6A	00	00	00	00	00	01	6A	F7
ZONE 6 PREV	F0	00	00	7F	00	05	70	05	02	02	00	00	67	00	00	00	00	00	01	68	F7
ZONE 6 NEXT	F0	00	00	7F	00	05	70	05	02	02	00	00	68	00	00	00	00	00	01	69	F7
ZONE 6 PLUS	F0	00	00	7F	00	05	70	05	02	02	00	00	69	00	00	00	00	00	01	6A	F7
ZONE 6 MINUS	F0	00	00	7F	00	05	70	05	02	02	00	00	6A	00	00	00	00	00	01	6B	F7

CONTROLLER #1 KEYPAD EVENTS - ZONE PLAY / STOP / PAUSE / F1 / F2 COMMANDS																					
	F0	00	00	7F	00	00	70	05	02	02	00	00	00	00	00	00	00	00	01	F7	
Byte Count	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21
ZONE 1 PLAY	F0	00	00	7F	00	00	70	05	02	02	00	00	73	00	00	00	00	00	01	6F	F7
ZONE 1 STOP	F0	00	00	7F	00	00	70	05	02	02	00	00	6D	00	00	00	00	00	01	69	F7
ZONE 1 PAUSE	F0	00	00	7F	00	00	70	05	02	02	00	00	6E	00	00	00	00	00	01	6A	F7
ZONE 1 F1	F0	00	00	7F	00	00	70	05	02	02	00	00	6F	00	00	00	00	00	01	6B	F7
ZONE 1 F2	F0	00	00	7F	00	00	70	05	02	02	00	00	70	00	00	00	00	00	01	6C	F7
ZONE 2 PLAY	F0	00	00	7F	00	01	70	05	02	02	00	00	73	00	00	00	00	00	01	70	F7
ZONE 2 STOP	F0	00	00	7F	00	01	70	05	02	02	00	00	6D	00	00	00	00	00	01	6A	F7
ZONE 2 PAUSE	F0	00	00	7F	00	01	70	05	02	02	00	00	6E	00	00	00	00	00	01	6B	F7
ZONE 2 F1	F0	00	00	7F	00	01	70	05	02	02	00	00	6F	00	00	00	00	00	01	6C	F7
ZONE 2 F2	F0	00	00	7F	00	01	70	05	02	02	00	00	70	00	00	00	00	00	01	6D	F7
ZONE 3 PLAY	F0	00	00	7F	00	02	70	05	02	02	00	00	73	00	00	00	00	00	01	71	F7
ZONE 3 STOP	F0	00	00	7F	00	02	70	05	02	02	00	00	6D	00	00	00	00	00	01	6B	F7
ZONE 3 PAUSE	F0	00	00	7F	00	02	70	05	02	02	00	00	6E	00	00	00	00	00	01	6C	F7
ZONE 3 F1	F0	00	00	7F	00	02	70	05	02	02	00	00	6F	00	00	00	00	00	01	6D	F7
ZONE 3 F2	F0	00	00	7F	00	02	70	05	02	02	00	00	70	00	00	00	00	00	01	6E	F7
ZONE 4 PLAY	F0	00	00	7F	00	03	70	05	02	02	00	00	73	00	00	00	00	00	01	72	F7
ZONE 4 STOP	F0	00	00	7F	00	03	70	05	02	02	00	00	6D	00	00	00	00	00	01	6C	F7
ZONE 4 PAUSE	F0	00	00	7F	00	03	70	05	02	02	00	00	6E	00	00	00	00	00	01	6D	F7
ZONE 4 F1	F0	00	00	7F	00	03	70	05	02	02	00	00	6F	00	00	00	00	00	01	6E	F7
ZONE 4 F2	F0	00	00	7F	00	03	70	05	02	02	00	00	70	00	00	00	00	00	01	6F	F7
ZONE 5 PLAY	F0	00	00	7F	00	04	70	05	02	02	00	00	73	00	00	00	00	00	01	73	F7
ZONE 5 STOP	F0	00	00	7F	00	04	70	05	02	02	00	00	6D	00	00	00	00	00	01	6D	F7
ZONE 5 PAUSE	F0	00	00	7F	00	04	70	05	02	02	00	00	6E	00	00	00	00	00	01	6E	F7
ZONE 5 F1	F0	00	00	7F	00	04	70	05	02	02	00	00	6F	00	00	00	00	00	01	6F	F7
ZONE 5 F2	F0	00	00	7F	00	04	70	05	02	02	00	00	70	00	00	00	00	00	01	70	F7
ZONE 6 PLAY	F0	00	00	7F	00	05	70	05	02	02	00	00	73	00	00	00	00	00	01	74	F7
ZONE 6 STOP	F0	00	00	7F	00	05	70	05	02	02	00	00	6D	00	00	00	00	00	01	6E	F7
ZONE 6 PAUSE	F0	00	00	7F	00	05	70	05	02	02	00	00	6E	00	00	00	00	00	01	6F	F7
ZONE 6 F1	F0	00	00	7F	00	05	70	05	02	02	00	00	6F	00	00	00	00	00	01	70	F7
ZONE 6 F2	F0	00	00	7F	00	05	70	05	02	02	00	00	70	00	00	00	00	00	01	71	F7

CONTROLLER #1 KEYPAD EVENTS - ZONE SOURCE SELECT COMMANDS																						
	F0	00	00	7F	00	70	05	02	00	00	00	F1	3E	00	00	00	00	01	F7			
Byte Count	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
ZONE 1 SRC 1	F0	00	00	7F	00	00	70	05	02	00	00	00	F1	3E	00	00	00	00	01	2A	F7	
ZONE 1 SRC 2	F0	00	00	7F	00	00	70	05	02	00	00	00	F1	3E	00	00	00	01	00	01	2B	F7
ZONE 1 SRC 3	F0	00	00	7F	00	00	70	05	02	00	00	00	F1	3E	00	00	00	02	00	01	2C	F7
ZONE 1 SRC 4	F0	00	00	7F	00	00	70	05	02	00	00	00	F1	3E	00	00	00	03	00	01	2D	F7
ZONE 1 SRC 5	F0	00	00	7F	00	00	70	05	02	00	00	00	F1	3E	00	00	00	04	00	01	2E	F7
ZONE 1 SRC 6	F0	00	00	7F	00	00	70	05	02	00	00	00	F1	3E	00	00	00	05	00	01	2F	F7
ZONE 1 AUX	F0	00	00	7F	00	00	70	05	02	00	00	00	F1	3E	00	00	00	06	00	01	30	F7
ZONE 2 SRC 1	F0	00	00	7F	00	01	70	05	02	00	00	00	F1	3E	00	00	00	00	01	2B	F7	
ZONE 2 SRC 2	F0	00	00	7F	00	01	70	05	02	00	00	00	F1	3E	00	00	00	01	00	01	2C	F7
ZONE 2 SRC 3	F0	00	00	7F	00	01	70	05	02	00	00	00	F1	3E	00	00	00	02	00	01	2D	F7
ZONE 2 SRC 4	F0	00	00	7F	00	01	70	05	02	00	00	00	F1	3E	00	00	00	03	00	01	2E	F7
ZONE 2 SRC 5	F0	00	00	7F	00	01	70	05	02	00	00	00	F1	3E	00	00	00	04	00	01	2F	F7
ZONE 2 SRC 6	F0	00	00	7F	00	01	70	05	02	00	00	00	F1	3E	00	00	00	05	00	01	30	F7
ZONE 2 AUX	F0	00	00	7F	00	01	70	05	02	00	00	00	F1	3E	00	00	00	06	00	01	31	F7
ZONE 3 SRC 1	F0	00	00	7F	00	02	70	05	02	00	00	00	F1	3E	00	00	00	00	01	2C	F7	
ZONE 3 SRC 2	F0	00	00	7F	00	02	70	05	02	00	00	00	F1	3E	00	00	00	01	00	01	2D	F7
ZONE 3 SRC 3	F0	00	00	7F	00	02	70	05	02	00	00	00	F1	3E	00	00	00	02	00	01	2E	F7
ZONE 3 SRC 4	F0	00	00	7F	00	02	70	05	02	00	00	00	F1	3E	00	00	00	03	00	01	2F	F7
ZONE 3 SRC 5	F0	00	00	7F	00	02	70	05	02	00	00	00	F1	3E	00	00	00	04	00	01	30	F7
ZONE 3 SRC 6	F0	00	00	7F	00	02	70	05	02	00	00	00	F1	3E	00	00	00	05	00	01	31	F7
ZONE 3 AUX	F0	00	00	7F	00	02	70	05	02	00	00	00	F1	3E	00	00	00	06	00	01	32	F7
ZONE 4 SRC 1	F0	00	00	7F	00	03	70	05	02	00	00	00	F1	3E	00	00	00	00	01	2D	F7	
ZONE 4 SRC 2	F0	00	00	7F	00	03	70	05	02	00	00	00	F1	3E	00	00	00	01	00	01	2E	F7
ZONE 4 SRC 3	F0	00	00	7F	00	03	70	05	02	00	00	00	F1	3E	00	00	00	02	00	01	2F	F7
ZONE 4 SRC 4	F0	00	00	7F	00	03	70	05	02	00	00	00	F1	3E	00	00	00	03	00	01	30	F7
ZONE 4 SRC 5	F0	00	00	7F	00	03	70	05	02	00	00	00	F1	3E	00	00	00	04	00	01	31	F7
ZONE 4 SRC 6	F0	00	00	7F	00	03	70	05	02	00	00	00	F1	3E	00	00	00	05	00	01	32	F7
ZONE 4 AUX	F0	00	00	7F	00	03	70	05	02	00	00	00	F1	3E	00	00	00	06	00	01	33	F7
ZONE 5 SRC 1	F0	00	00	7F	00	04	70	05	02	00	00	00	F1	3E	00	00	00	00	01	2E	F7	
ZONE 5 SRC 2	F0	00	00	7F	00	04	70	05	02	00	00	00	F1	3E	00	00	00	01	00	01	2F	F7
ZONE 5 SRC 3	F0	00	00	7F	00	04	70	05	02	00	00	00	F1	3E	00	00	00	02	00	01	30	F7
ZONE 5 SRC 4	F0	00	00	7F	00	04	70	05	02	00	00	00	F1	3E	00	00	00	03	00	01	31	F7
ZONE 5 SRC 5	F0	00	00	7F	00	04	70	05	02	00	00	00	F1	3E	00	00	00	04	00	01	32	F7
ZONE 5 SRC 6	F0	00	00	7F	00	04	70	05	02	00	00	00	F1	3E	00	00	00	05	00	01	33	F7
ZONE 5 AUX	F0	00	00	7F	00	04	70	05	02	00	00	00	F1	3E	00	00	00	06	00	01	34	F7
ZONE 6 SRC 1	F0	00	00	7F	00	05	70	05	02	00	00	00	F1	3E	00	00	00	00	01	2F	F7	
ZONE 6 SRC 2	F0	00	00	7F	00	05	70	05	02	00	00	00	F1	3E	00	00	00	01	00	01	30	F7
ZONE 6 SRC 3	F0	00	00	7F	00	05	70	05	02	00	00	00	F1	3E	00	00	00	02	00	01	31	F7
ZONE 6 SRC 4	F0	00	00	7F	00	05	70	05	02	00	00	00	F1	3E	00	00	00	03	00	01	32	F7
ZONE 6 SRC 5	F0	00	00	7F	00	05	70	05	02	00	00	00	F1	3E	00	00	00	04	00	01	33	F7
ZONE 6 SRC 6	F0	00	00	7F	00	05	70	05	02	00	00	00	F1	3E	00	00	00	05	00	01	34	F7
ZONE 6 AUX	F0	00	00	7F	00	05	70	05	02	00	00	00	F1	3E	00	00	00	06	00	01	35	F7