How to Install Forté A-BUS

Developer Packs

Installation can be done in 7 Easy steps.


ABK-4RJ & RCA Wallplate

LeisureTech recommends installation by an A-BUS qualified installer. For installers in your area visit <u>LOCATOR</u> to find the closest one in your area.

For worry free installation use A-BUS manufactured speaker cable.

Step 1 **Design placement**

- a Work out best placement of speakers take into consideration the following:
- 1 roofing beams
- depth of roof cavity, check with speaker being installed. Suggested minimum 80mm depth for Forte speakers
- 3 avoid any major power cables
- b Place AB-70 dock in a central loca tion, eg; kitchen, hallway, lounge




Step 2 Install Cable

- a Pre-wire DL-8 (CAT5e) in a star pattern from distribution hub (fig 1)
- b Run DL-8 (CAT5e) from iPod dock to distribution hub (*fig1*)
- c Label each cable with destination name (fig 2)
- d Run speaker cable from slave speaker to amplified IR speaker
- e Terminated both ends with RJ-45 connection in T568A configuration (fig 3)
- f Test cable, connections and terminations with RJ-45 LAN tester

Step 3 Mount Hub

- a Locate distribution hub in central location, near power
- b Connect RJ-45 terminated cables from 1-4 rooms to hub (fig 4)
- c Connect RJ-45 terminated cable from AB-70 (OUT) to ABK-4RJB (IN) (fig 4)





ABK-4RJB

FIG 4

Step 4 Connecting AB-70 module

a Cut hole to a standard single-gang wall plate size (75mm H x 45mm W)

- b Pull cable through
- c Connect RJ-45 terminated cable to module (fig5)
- d Screw on to wall



FIG 5

Step 5 A-BUS/DIRECT Speakers

- a Cut hole to speaker cut out dimensions (Forte 6.5" = 206mm dia x 79mm depth)
- b Pull cable through
- c Connect RJ-45 terminated cable to Amplified IR speaker (fig 6)
- d Connect speaker wire between the two to the clip terminals (fig 6)
- e Do not screw into ceiling yet



Step 6 Power up

- a Turn on power supply
- b Turn on iPod and press play
- c Turn volume up on Amplified speakers in each room, confirm music is playing.



Step 7 Final set up

- a Turn volume up to maximum required level then adjust the trimpots on back of Amplified IR speaker. This sets max volume level (fig8)
- b Screw speakers into ceiling
- c Test Source volume from each room, by pointing remote at Active IR speaker and change volume (+/-)
- d When using single IR speaker select mono on back of speaker (fig 9)
- e For programming keypad with wall cradle, see ABR-43 (fig 7) instructions



FIG 9

FIG 7

